

This kind of product is a section of advanced MINI DV productswhich is put out to market demand. It has the functions of advan ced digital video, taking pictures,recording and PC camera. The appearance isexquisite. It is esthet ic and practical and easy to carry.

Parameter

Resolution	2.0MCMOS
View Angle	7 degree
Minimum Illumination	1 Lux
Battery Capacity	360MAH
Continuons Recording Time	2.5 hours
Memory Capacity	Up to 8GB
Video Compression	.AVformat
Video Resolution	l280x960 pixels
Recording Frame Rate	30 Fps
Storage Temperature	-2o-c-so·c
Operation Temperature	-JO"C-so-c
Operation Humidity	l5-85%RH
USB Interface	USBI.l/2.0
Operation System	2000/XP/VISTA32
Store and Consume	IGB/40 minutes
Charging Time	2 hours

Notice: Please be subject to the actual product **if** anything different caused by update.

User Manual of Diving Mask DVR

(with HO video camera)

Content

Foreword .. …..1

Product guarantee. ...1

Product brief.. …….2

Product features …..2

Product diagram. .3

How to use.. ..4-7

Operation step.. …..8-9

Store and play files.. ……10

PC video camera function.. ……11

Tirne setting. ……11

Reset.. .12

Adapter.. .13

Accessories. . .13

Parameter.. ..14

Adapter

This product a)ways conforrns to the authenticated AC adapter. The adapter should be marked one of the following:



Notice: It's a normal phenomenon that adapter 's surface temperature possibly rises when charging. Please remove the adapter from the outlet **if** you need take it along.

Accessories

Adapter, USB cable, CD disk,

Head strap, Buckle, Snorkel set, Manual

Reset

When the product is because of illegal operation or other reasons not known to stop responding, you need to reset the product; to reset when you unplug the USB plug, use a toothpick-like object into the USB hole, hold down the inside of the switch can reset successfully.

Note: Do not reset the action carried out in the water to prevent leakage: press reset button does not save the video file shutdown.

Foreword

Thanks for taking our product. This diving mask is designed for underwater sports, wearing comfortable, with excellent sealing performance and unique streamlined shape. It can take video and picture in underwater surrounding.

The manual will guide you how to use & wear the diving mask, also supply ali detailed information you need, including operation step and technical parameter. Please read the manual carefully before you use our product, and keep it in a safe place. We hope you would be satisfied both with our product and service.

Product guarantee

This product bas passed FCC & CE authentication, and ali components full meet recommended standard. User security is certain absolutely.

Product brief

This product launched to meet market demand is a high leve! digital camcorder for underwater use. It's integrated with the advanced functions of digital video recording, camera, USB data transmission and USB charging.

Product features

1. Motional video recording, instant respond to surrounding light;
2. 2.0M CMOS;
3. Video resolution: 1280x960, 30 fps;
4. Built-in Li-battery, continuons photographing for about 2 hours;
5. Support nand-flash up to 8GB;
6. Unique magnet switch control, indicating by motor shaking;
7. Humanization design, wearing comfortable;
8. With PC video camera, let you enjoy internet live **more;**
9. Video format in AV!, picture format in JPG, direct display on computer;
10. Tempered glass lens with strong antifog function, irmovative mask design, wide view.

PC video camera function

The diving mask also can be used as a PC video camera. Attached driver software in CD should be installed into computer before use. Let the magnet ring approach CAMERA key, and connect the mask to computer. It would appear a standard video equipment on computer, keeping the ring away, then you canuse it as a PC video camera.

Time setting

Set up a file named TI.ME.TXT with the below content form:2007.04.22 11:20:30

The corresponding mformation is Year *1* Month *1* Date *1* Hour Ivfinute / Second.

Copy this file to the root directory of the mask disk, then remove it safely from computer. Power on the mask, and record then power off. *Y*ou will see the time setting is OK done.

Store and play files

Connec!thmask to computer by USB cable, you can copy or eut ali pictureivideo files to computer theu play directly(Media player, KM player is recommended).



Notice: The cable's earphone end should be inserted into mask, and the other end should be inserted into USB slot in computer. Please do not connect computer while recording video or photographing.

Product diagram





How to use

1. How to fix the waterproof rubber plug

Hold the handle of rubber plug, and insert it into USB hole with force. Make sure the rubber plug's cylinder part is in USB hole completely.

Illustration:



(1) (2)

Notice: Please make sure the waterproof rubber plug is fixed successfully before diving, in case water dripping.

2. How to fix the head strap

Draw one end of the head strap through the buckle's bigger hole, then draw it out of the mask's

approach CAMERA key again , save recording ,magnet approach 3seconds,the motor shaking 2 times for a short time. in save recording during still Video status.

(5) In the Power off status : USB Connect PC is U disk ,the motor shaking once a time.

(6) In the Power NO status , the motor shaking connect USB is PC camera .

(7) Charging; Connect USB the motor shaking 1 time, When Charge full shake every 15 seconds.

(8) Card full: long shaking

(9) Low power: When it detects battery is in low power, the motor would shake twice for a long time then power off.

Operation

1.ON/OFF KEY

2. CAMERA KEY : video/photo KEY

(1)Power on: in the status of OFF, let the magnet ring approach PLAY key for 2 seconds, the motor would shake once for a long time(about 3 second),it's standby now.

(2) Power off: in the status of Standby, let the magnet ring approach PLAY key for 2 seconds,

(3) Photographing: in the status of Standby, let the magnet ring approach CAMERA KEY 1second,it would start to take a photo then store ,the motor shaking once for a short time.

(4) Video: in the status of standby, let the magnet ring approach CAMERA KEY for 3 seconds, in the status of recording, let the magnet ring

hole (the serrated face is closed to glass). Adjust it into a suitable size after drawing into the buckle's smaller hole. The other end is same.

Illustration:



3. How to fix the snorkel set

Lace the active button to head strap, it's adjustable.

Illustration:

(1)

(2)

Notice: Sew up your mouth while the mouthpiece is bitten on, and snorkel tube should close to your ear. To avoid water entering the tube from surface, you should inhale slow and exhale quick, so thal the remaining water would be drawn out of the tube. You should lake a deep inhalation before diving, then lead water away after the snorkel tip is above the surface.

4. How to JIX the diving mask

1) Put the mask on your face soft!y and look up, keep ing the head strap smooth.

2) Inhale air peacefully by nose and make the mask being stable in a certain position.

3) Draw the strap to the back of head and adjust in a comfortable state. Too tight or loose would cause water dripping both.

Notice:

!. We have enhanced the inside glasses' antifog function, please do not polish it direct by your hand or rough elath in case scratch;

2. Clear the mask by water and keep it in a dry place **after use:**

3. In case of aging please do not wash the silicon by other organic material. The mask can't be crushed;

4. Please do not expose to the sun